


FR95

D811170 11-01-99 Vers. 03



AUTOMATION FOR INDUSTRIAL SECTIONAL DOORS



We declare that this product is in conformity with the following European Directives:

89/336/EEC (amended by RL 91/263/CEE, 92/31/CEE and 93/68/EEC), 73/23/CEE (amended by RL 93/68/CEE).

1) GENERAL OUTLINE

This controller has been designed to motorize residential and industrial sectional doors.

The compactness and versatility of the installation allow the motor drive to be fitted in a variety of ways.

The controller is available in the following versions:

FR95-C	Version with possibility of manual chain-opening and closing.
FR95-CM	Version with possibility of manual chain-opening and closing and release mechanism for maintenance (the release mechanism disengages the drive from the cable winder shaft of the door).
FR95-SB	Version with quick release for fast manual opening and closing. The door should be perfectly balanced.

Safety microswitches protect each manual manoeuvre command.

The motor is supplied with an electro-mechanical brake to make the gear-motor irreversible.

2) TECHNICAL SPECIFICATIONS

VOLTAGE	Single-phase 230V $\pm 5\%$ 50Hz Three-phase 400V $\pm 5\%$ 50Hz
ABSORPTION	Single-phase 1.7 A Three-phase 0.8 A
POWER	Single-phase 0.25 Kw (Hp = 0.33) Three-phase 0.33 Kw (Hp = 0.45)
MOTOR	1400 RPM (revs./min)
CAPACITOR	12.5 μ F + 16 μ F (starting)
BRAKE	Mechanical
INSULATION CLASS	F
THERMAL PROTECTION	130°C self-resetting
REDUCTION GEAR	OIL AGIP ALER 68
REDUCTION GEAR RATIO	1/43
OUTPUT REVS.	33 RPM
THROUGH-SHAFT	1" ($\varnothing$ 25.4 mm)
SPEED	8m/min with Z=18 1/2" x 5/16" (fig.4)
MAX DOOR WEIGHT	Single-phase 350 daN (Kg)=25 m ² Three-phase 700 daN (Kg)= 40 m ²
TORQUE PROVIDED	Single-phase 5 daN (Kgm) Three-phase 6 daN (Kgm)
IMPACT REACTION	Stop and reverse (with pressure sensitive edge)
DRIVE	Link chain or direct drive
LIMITING DEVICES	Built-in limit switches
CONTROL UNIT	Mizar (single-phase) Sirio TN1 (single-three-phase)
MANUAL MANOEUVRE	With chain for FR-C/CM Rapid for FR95-SB (FR95-CM)
NUMBER OF MANOEUVRES	100 Manoeuvres/24h
WORKING TEMPERATURE	-15 + 60° C
PROTECTION	IP 55
CONTROLLER WEIGHT	9 Kg
DIMENSIONS	See fig. 1

3) INSTALLATION OF AUTOMATION

Preliminary checks

Check the balancing of the door.

Check that the door slides along the whole of its stroke.

Check the safety devices (parachute-type, cables etc.).

If a new door is not being installed, check whether the door and its components are worn.

Repair or replace any worn or damaged parts.

Automation reliability and safety are directly influenced by the condition of the sectional door's structure.

4) CONTROLLER INSTALLATION

WARNING: Before fastening the controller, check whether the protection wedge "P" (fig. 10) is present in the adjustment limit switch unit. The protection wedge prevents damage to the limit switch unit when manual opening checks are made before adjusting the limiting microswitches.

The controller can be installed on both the right or left of the sectional door.

Direct drive

The cable winder shaft of the sectional door ($\varnothing = 1" \varnothing 25.4$ mm) should have a key way and can be inserted directly into the through shaft of the controller. The controller is directly fastened to the cable winder shaft support (fig. 2) or to the wall using special brackets. Some manufacturers of sectional doors supply joints with shaft for these types of motor drives.

This type of installation is suitable for sectional doors with cable winders, which have a diameter not exceeding 80 mm in order to comply with the maximum speed of movement required by current standards (e.g.: in Italy the maximum speed for UNI8612 standards is 8m/min).

Drive with reduction ratio.

The cable winder shaft is driven by a chain drive which may have reduction gears.

The gearmotor is fastened to the wall by means of the bracket provided (fig. 3).

The drive dimensions should be in accordance with the diameter of the cable winder for lifting the sectional door.

The vertical movement speed must correspond to the speed required by current standards (e.g.: in Italy the maximum speed for UNI8612 standards is 8m/min).

E.g.: If the sectional door is fitted with a 140mm diameter cable winder, to obtain an upstroke speed of approx. 8m/min, a crown wheel must be fitted which has a pitch diameter

$\varnothing p = 140$ mm corresponding to a 36-tooth crown wheel for a 1/2" x 5/16" link chain.

For this type of installation, a shaft with an 18-tooth pinion for a simple 1/2" x 5/16" chain (fig. 4) can be supplied as an accessory.

The chain tension is adjusted by moving the motor along the grooves in the anchoring bracket (fig. 5).

CAUTION: The chain drive should be protected in compliance with current standards.

5) ELECTRICAL INSTALLATION SET-UP

Arrange the raceways for the connections as shown in fig. 6. Keep the power supply connections separate from the limit switches connections.

Fit an omnipolar circuit breaker, with a contact opening of at least 3 mm, which has protection against overloading and can be used to disconnect the automation from the mains.

The Sirio-FR and Mizar-FR control panels are equipped with lockable cut-out switches and fuses (fig. 7). A radio control single-twin channel receiver can be inserted on the control boards.

Connection without the control unit can only be carried out in the single-phase version and for "hold-to-run" control. Only use buttons with at least 10A-250V capacity (fig. 8).

6) CONNECTION TO TERMINAL BOARD

Fig. 8 shows the connection of the single-phase and three-phase gearmotor to the terminal board.

For the electrical connection to the control unit, reference should be made to the manual of the control unit.

7) LIMIT SWITCH ADJUSTMENT (fig. 9)

The limit switch unit is situated on the head of the drive and is the system of adjustment. To gain access to the adjustment unit, dismantle the pinion-type quick release system, if any, and the box which covers the unit.

The microswitches are activated by two toothed cams which are locked in position by a holding spring.

When the door is closed, the "door closed" adjustment cam should activate the closing limit switch.

When the door is open, the "opening" adjustment cam should activate the opening limit switch.

Fig. 9 shows the position of the closing and opening limit switches in relation to the type of installation carried out.

If the adjustment cams are rotated towards each other, the stroke is increased. If the adjustment cams are rotated away from each other, the stroke is decreased.

The limit switch unit is equipped with a protection wedge "P" (fig.10) to prevent damage to the limit switches during manual installation manoeuvres.

8) LIMIT SWITCH CAM ADJUSTMENT

WARNING: For safety reasons, microswitch adjustment must be carried out with the power supply off.

The adjustment unit is fitted with four microswitches: 2 act as limiting devices and 2 act as safety overstroke devices.

The overstroke microswitches, if intercepted by the cams, bring the system

to a complete halt. This may be caused by an incorrect connection or a faulty limiting microswitch. If, during installation or maintenance, the cam intercepts an overstroke microswitch, the system will not accept any commands: the cam which intercepted the overstroke microswitch must be moved manually and the reason why the microswitch was intercepted must be established. Also make sure that the quick release mechanism or the manual chain-opening system have not been activated. Both these manual manoeuvre systems are equipped with safety microswitches which, if activated, block any electrical command.

To adjust the end of the stroke proceed as follows:

- Close the door manually, keeping it slightly raised above the ground.
- Identify the closing microswitch according to the installation position of the gearmotor (fig. 9).
- Remove and dispose of the protection wedge "P" which places the limit switch drive (fig.10) in neutral.
- Lift the holding spring from the cam teeth using a screwdriver (fig. 11).
- Turn the cam in the direction of the closing microswitch until the triggering of the first limiting microswitch can be heard.
- Lower the spring until it engages with a cam tooth.
- Supply the system with power and give the start command to carry out the opening manoeuvre.

WARNING: If the motor rotates in the opposite direction, then vary the connections as follows:

- In the single-phase version (fig. 8), invert the two connections in the power supply terminals of the motor "M1-M2".
- In the three-phase version (fig. 8), invert two phases in the power supply terminals of the motor "U-V-W".
- Give the stop command when the door is near to the opening end-of-stroke stop.
- Disconnect the power supply and lift the holding spring from the cam teeth using a screwdriver (fig. 11).
- Turn the cam in the direction of the microswitch until the first triggering of the opening limiting microswitch can be heard.
- Lower the spring until it engages with a cam tooth.
- If the door stops during opening, keep trying to move the cam manually until complete opening is obtained.
- Check that opening and closing stops are carried out without traction or compression of the sectional door.
- Repeat the complete opening and closing manoeuvre a few times to check whether the limiting microswitches are activated correctly. If this is not the case, adjust the position of the cams as necessary.
- Whenever end-of-stroke adjustments are carried out, the cam holding spring must always be replaced in the teeth of the two adjustment cams.
- Re-fit all the parts which were previously removed for adjustment of the limit switches.

9) EMERGENCY MANOEUVRE

If there is no power or because of a breakdown of the system, carry out the manoeuvre manually according to the system model. The system is equipped with special microswitches which disconnect the motor automatically during manual opening or quick release of the door.

FR95-C Manual opening or closing of the door can be obtained by pulling the jack chain which rotates the motor shaft in the required direction.

FR95-CM Manual opening or closing by means of the chain can be obtained in the same way as for model FR95-C. The release necessary for maintenance operation is obtained by introducing a CH = 8 mm Allen wrench into the quick release shaft and rotating it by approx. 90° clockwise. The release disengages the transmission of the motion to the cable winder shaft of the door so that the door can be manually operated. As soon as the shaft is rotated counterclockwise, the mechanical and electrical connection of the gear-motor is reset.

FR95-SB The door can be released by pulling the cord located on the right side and rotating the release shaft by 90° clockwise. The door can be manually operated when it is perfectly balanced.

10) AUTOMATION CHECK

Before making the automation definitely operative, carefully check the following:

- Check that all components are safely mounted in the right positions.
- Check the correct functioning of all safety devices (limit microswitches, photocells, sensitive cushions etc.).
- Check that the thrust (anticrushing) force of the door stops the system within the limits foreseen by the regulations in force.

Check the emergency function control.

Check the opening and closing operation with the applied control devices.

Check the electronic logic of normal and personalised functioning, in the event that a control unit is installed.

11) USE OF THE AUTOMATION

As the automation can be controlled at a distance by means of remote control or start push-button, and therefore not at sight, it is indispensable to control frequently the perfect efficiency of all safety devices. For any functioning anomaly, intervene rapidly even with the help of qualified personnel. We recommend to keep children at a suitable distance from the range of action of the automation.

12) CONTROL

The use of the automation allows the opening and closing of the door in a motorised way. The control can be of different types (manual, with remote control, access control with magnetic badge etc.) according to the necessity and the characteristics of the installation. For the various control systems, see the relative instructions.

The users of the automation must be instructed about its control and use.

13) MAINTENANCE

For any maintenance, disconnect the system from the power supply.

Check periodically for oil leakages from the radiator.

Check the condition of the toothed belt of the limiting devices and replace it if damaged.

Check periodically the drive unit and lubricate it as much as necessary (only for chain reduced transmission).

Check all the safety devices of the door and motor unit.

For any functioning anomaly, not solved, disconnect the system from the power supply and request the intervention of qualified personnel (installer). During the out of order period, activate the manual release in order to allow the manual opening and closing.

Fig. 1 NEW




Fig. 2 NEW




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 11




Fig. 9




Fig. 10




Fig. 12

