



OWNER'S MANUAL

Network Video Server

Please read this manual carefully before operating your set and retain it for future reference.

MODEL
LVS301
LVS311

P/NO : MFL62591920



CAUTION

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK
DO NOT REMOVE COVER (OR BACK)
NO USER-SERVICEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

FCC WARNING: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

REGULATORY INFORMATION: FCC Part 15

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- A suitable conduit entries, knock-outs or glands shall be provided in the cable entries of this product in the end user.
- Caution: Danger of explosion if battery is incorrectly replaced. Replaced only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.
- Holes in metal, through which insulated wires pass, shall have smooth well rounded surfaces or shall be provided with brushings.

This Class A digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Warning: Do not install this equipment in a confined space such as a bookcase or similar unit.

Warning: Wiring methods shall be in accordance with the National Electric Code, ANSI/NFPA 70.

Warning: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Warning: To reduce a risk of fire or electric shock, do not expose this product to rain or moisture.

Caution: This installation should be made by a qualified service person and should conform to all local codes.

Caution: To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Caution: The apparatus shall not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, shall be placed on the apparatus.

To disconnect power from mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily accessible.



LG Electronics hereby declares that this/these product(s) is/are in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC, 2006/95/EC, and 2009/125/EC.

European representative :

LG Electronics Service Europe B.V. Veluwezoom 15,
1327 AE Almere. The Netherlands
(Tel : +31-(0)36-547-8888)

Disposal of your old appliance



1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



Cautions for Safe Operation

Handling of the unit

Be careful not to spill water or other liquids on the unit. Be cautious not to get combustible or metallic material inside the body. If used with foreign matter inside, the device is liable to fail or to get cause of fire or electric shock.

- Use a dry soft cloth to clean the body. If it is very dirty, use a cloth dampened with a small quantity of neutral detergent then wipe dry.
- Avoid the use of volatile solvents such as thinners, alcohol, benzene and insecticides.
They may damage the surface finish and/or impair the operation of the device.

Operating and storage location

Avoid viewing a very bright object (such as light fittings) during an extended period. Avoid operating or storing the unit in the following locations.

- Extremely hot or cold places (operating temperature from -10 °C to 50 °C, however, we recommend that the unit be used within a temperature range from 0 °C to 45 °C)
- Damp or dust place
- Places exposed to rain
- Places subject to strong vibration
- Close to generators of powerful electromagnetic radiation such as radio or TV transmitters.

Contents

Introduction	7	Accessing the LG IP device.....	19
Front Panel.....	8	LG Smart Web Viewer Overview	21
Rear Panel	9	Configuring the LG video server.....	22
 Connections	11	 Reference	40
Precautions.....	11	Troubleshooting	40
Connection Overview.....	11	Open source software notice.....	43
Connecting Camera	12	Specifications.....	46
Connecting Display Device	12		
Connecting Network.....	13		
Connecting Power Source	14		
Connecting RS-422/RS-485 Device.....	15		
Connecting Alarm Device.....	16		
Connecting Microphone and Speaker Device.....	17		
Wall Mounting.....	18		
 Operation and settings	19		
Before using the system	19		
Recommended PC Requirements.....	19		

Introduction

The LG Video Server is designed to use on an Ethernet network and must be assigned an IP address to make it accessible.

This manual contains instructions on how to install and manage the Video Server in your networking environment. Some knowledge of networking environments would be beneficial to the reader.

Should you require any technical assistance, please contact authorized service center.

Features

The LG Video Server offers the following functions:

- Dual H.264 Stream for single Video Input
- Multi-Codec (H.264, MJPEG) Streaming
- Intelligent Video Analysis (Option)
- PoE (Power over Ethernet) Support (802.3af)
- 3 Power (AC 24 V, DC 12 V, PoE) Support
- Audio Support (G.711, G.726 Full Duplex)
- Pre/Post Alarm Support
- Remote Pan/Tilt/Zoom Control (RS-422, RS-485 support)
- Direct NAS Writing

Features Chart

This table shows the differences between the models.


Use LVS311 is used for the description, operations and details provided in this user manual.

Models	LVS301	LVS311
VCA	No	Yes
PTZ	Yes	Yes
PRESET	Yes	Yes
Fan Fail Notification	No	No
Fan & Heater Temperature	No	No

Accessories


- Mounting bracket
- Program CD
- User Manual

Front Panel



- 1** POWER Indicator: Lights when the LG Video Server is powered.
- 2** NETWORK Indicator: Lights when a network cable is connected.
- 3** VIDEO Indicator: Lights when the camera is connected.
- 4** SENSOR Indicator: Lights when the alarm out is in progress.

Rear Panel



- 1 VIDEO INPUT**
Connect the camera's video output to this BNC connector.
- 2 RS-485/RS-422 Terminals**
Connect RS-485/RS-422 compatible cameras.
- 3 SENSOR IN Terminal**
Input terminal for sensor signal.
- 4 RELAY OUT Terminals**
Output terminals for alarm (relay) signal.

5 RESET button

Push the button more than 3 seconds, this would restore the factory default settings.

6 RS-485/RS-422 Dip Switch

The default position of the dip switch and function are as shown below.

	Position	SW1	SW2	SW3	SW4
	ON	RS-485	RS-485 HALF		TERMINATION ON
	OFF	RS-422	RS-485 FULL		TERMINATION OFF

7 VIDEO OUT

Supplies analog video signal (composite) to the connected device.

8 AUDIO OUT (Line Level Output)

Connect to an active speaker with a built-in amplifier.

9 AUDIO IN (Line Level Input)

Input for a mono microphone, or a line-in mono signal.

10 ETHERNET/POE Port

Connects to a PC or a network via a hub with a 10 BASE-T/100 BASE-TX cable attached RJ-45 connector.

Note:

Power over Ethernet (PoE) is a technology that integrates power into a standard LAN infrastructure. It enables power to be provided to the network device, such as a network camera, using the same cable as that used for network connection. It eliminates the need for power outlets at the device locations and enables easier application of uninterruptible power supplies (UPS).

11 Power input terminal


Connects to a DC 12 V or AC 24 V power supply using proper cables.

Connections

Precautions


- Be sure to switch off the unit before installation and connection.
- The installation should be made by qualified service personnel or system installers.
- Do not expose the power and connection cables to moisture, which may cause damage to the unit.

Connection Overview




Connecting Camera

Connect the video output of your camera to the LG Video Server, using a standard 75 Ω video coaxial cable with BNC connector. There are two BNC connectors. Either connector can receive a camera's signal. This signal is looped-through (directly connected) to the other connector, so that you can send the camera's signal to other equipment.



Connecting Display Device


The video signal connection between the LG Video Server and the monitor.



Connecting Network

You can control and monitor the system via network. With the remote control (monitoring), you can change the system configuration or monitor the image via network. After the installation, check the network settings for the remote control and monitoring work.

Connect the LG Video Server to your network using a standard RJ-45 network cable as shown below.




Connecting Power Source

Connect power, using one of the methods listed below:

To use the power adapter


Connect a DC 12 V / AC 24 V power source to the power input terminal as shown below.

1. Remove the insulation on the power cable as illustrated.
2. Attach the terminal tips.
3. Connect to the DC 12 V / AC 24 V UL Listed, Class 2 Power Supply only on the unit.



To use the PoE (Power over Ethernet) device

Connect the PoE cable to the LAN port on the unit. You must use the “IEEE802.3af” standard PoE device.




Note:

If the video server doesn't work properly after connect PoE device, please check if the PoE device is supplying enough power.

Connecting RS-422/RS-485 Device


Use these ports to connect PTZ Device or an external device of RS-422/RS-485 format.

RS-422 device : Set the dip-switch to RS-422 mode and connect as shown below.



Termination OFF	Termination ON

RS-485 device: Set the dip-switch to RS-485 mode and connect as shown below.



	Termination OFF	Termination ON
RS-485 HALF		
RS-485 FULL		

Notes:


- If you set the Termination S/W to ON, you must use the input impedance to 120 Ω.
- Do not use the multiple RS-422/RS-485 device to connect the unit, it may cause the malfunction.

Connecting Alarm Device

Alarm terminals are used to connect the alarm (relay) devices such as sensors, door switches, etc.


Sensor Input

Connect the sensor device to the sensor input terminal.



Relay Output

Connect the alarm (relay) device to the relay output terminal. Alarm signal is outputted at an event occurrence.




Note:

The internal switching relay is rated for 0.3 A at 125 V AC or 1 A at 30 V DC.

Connecting Microphone and Speaker Device

Optionally connect an active speaker and/or external microphone with a built-in amplifier.




Note:

Keep the microphone away from the speaker to avoid howling.

Wall Mounting

The LG Video Server is supplied with a mounting bracket for wall mounting. The mounting bracket can be positioned for mounting the video server on a vertical surface. Follow the instructions below to attach the brackets to the video server:

1. Install the mounting bracket to the wall with four screws.
2. Assemble the LG Video Server and mounting bracket. (Connect the unit by following step **1** and **2**.)
3. Connect the cables to the terminals on the LG Video Server.



Operation and settings

Before using the system

- Before using the LG IP device make sure the connections are correct and verify whether proper power supply is used.
- Check the connections and the LED indicator of the LG Video Server for the correct conditions.
- Check that the LG IP device is(are) connected to the network and that power is supplied.
- Once the connections are made you need to install the LG client program to the PC from which you want to access the device. The LG Smart Web Viewer program is automatically installed when you connect the LG IP device. The LG Smart Station and the LG Smart Web Viewer program are the network program of the LG Video Server and the LG IP cameras.
- JRE (Java Runtime Environment) is a pre requisite for LG Smart Web Viewer program. If this is missing in the PC please install the same manually from "http://java.sun.com" website. (Version 1.6.0.11 or later)
- The Layouts and the Live view pages may differ with different OS (Operating Systems) and Web Browsers.
- Care needs to be taken not to run any other applications when the Client Program is running as it may cause memory shortage.

Recommended PC Requirements

The LG IP device can be used with most standard operating systems and browsers.

Items	Requirements
Operating System	Windows XP Professional or above
CPU	Intel Core2 Quad Q6700 (2.66 GHz) or above
Web Browser	Microsoft Internet Explorer 6.0 or higher
DirectX	DirectX 9.0 or above
Memory	2 GB or above RAM
Graphics Card	256 MB or above Video RAM
Resolution	1280 x1024 (with 32 bit color) or higher

Accessing the LG IP device

You can access the LG IP device by following the below steps.

1. Copy the IP Utility to your PC

- 1.1 Insert the Client Program CD.
- 1.2 Find and Copy IP Utility folder to your PC.

2. Discover the LG IP device using the IP Utility

The IP Utility can automatically discover and display LG IP devices on your network. The IP Utility shows the MAC address, IP address, Model name and so on.

Note:

The computer running the IP Utility must be on the same network segment (physical subnet) as the LG IP device.

- 2.1 Run the IP Utility program.
- 2.2 Click the [Search] icon or select the [Search] option in the Device search menu.
After a few seconds the found LG IP devices gets displayed in the IP Utility window.

3. Logging in to the LG Smart Web Viewer


The LG Smart Web Viewer can be used with most web browsers. The recommended browser is Internet Explorer with Windows.

- 3.1 Run the IP Utility and find the LG IP devices.
- 3.2 When the LG IP devices appear in the IP Utility window, double-click IP address or right click on the same IP address and select "Connect to Web Page" to start the LG Smart Web Viewer. When accessing the LG Smart Web Viewer, the authentication dialog appears on the screen.
- 3.3 Enter the user ID and password. (Note that the default administrator user ID and password are "admin".)
- 3.4 Click the [OK] button and then the LG Smart Web Viewer is displayed in your browser.


Notes:

- You can also access the LG Smart Web Viewer as shown below.
 - 3.1 Start your Web browser.
 - 3.2 Enter the IP address of the LG IP device in the address bar of the browser.
 - 3.3 Enter the user ID and password set by the administrator.
 - 3.4 Click the [OK] button and then the LG Smart Web Viewer is displayed in your browser.
- The LG Smart Web Viewer needs more time to display it according to the network conditions.
- If the login window is not displayed, check the pop-up blocker. If you set the pop-up blocker, the login window is not displayed. You must allow the pop-ups.
- If you connect the LG Smart Web Viewer for the first time, the Security Warning window is displayed to install the LG Smart Web Viewer program. You must install the LG Smart Web Viewer program for using the LG IP device.
- If your computer or network is protected by a proxy or firewall, the proxy or firewall settings can prevent the LG Smart Web Viewer program. Change the proxy or firewall settings to activate the LG Smart Web Viewer program.

LG Smart Web Viewer Overview



Item	Description
Change view size AUTO	Select the video image size from the drop-down list. (AUTO, D1, CIF or QCIF) The initial view size is set to AUTO. The AUTO option sets the view size according to the Server's resolution.
Video codec H.264	Displays the current video codec of the selected video stream (Master or Slave).
TCP connection ☒	Check this option as the network connection type (TCP or UDP). If you check it, the client connects to the server using TCP connection.

 Snapshot	Click to save the current image in JPEG format on your computer. 1. Click the [Snapshot] button and then the Snapshot window is displayed. 2. Click the [Save] button in the Snapshot window. 3. Enter the file name (JPEG format) and select the folder to save it. 4. Click the [Save] button to confirm it. 5. Click the [Close] button in the Snapshot window to close it.
 PTZ control	Displays the PTZ control window. Use these buttons to control the PTZ unit. This button is not displayed with normal or anonymous user.
 OSD control	Displays the Camera OSD control window. Use these buttons to setup the Camera. This button does not appear on the screen if the login is other than the administrator.
	Select the video stream. From the Live view drop-down list, select the desired video image source between [Master-0] and [Slave-0]. Note: Master and Slave are output video streams. You can set the stream configurations independently for either Master or Slave stream. This would facilitate the user to set the live view at his comfort.

	Provides all the necessary tools for setting up the device to your requirements. The user will need administrator level to do this. Note: If you want to exit the Configuration menu, select one of the video stream in the Live view drop-down list.
	Displays the current surveillance live screen. You can monitor the camera image on the live view window of the LG Smart Web Viewer.
	Click this button to connect or disconnect the audio communication between the LG IP device and the connected PC. (Color icon: On, Gray scale icon: Off.)
	Click this button to switch the microphone off and on for the computer. (Color icon: On, Gray scale icon: Off.)
	Click this button to switch the sound off and on, for the speaker of the computer. (Color icon: On, Gray scale icon: Off.)

Configuring the LG video server

The features and options of the LG video server are configured through the Configuration menu.

Only administrator-level users have permission to access the Configuration menu.

Accessing the Configuration menu

Click the [Configuration] button to display the LG Smart Web Viewer configuration window.

Warning

The Configuration setup should be made by qualified service personnel or system installers.

Configuration menu overview

The following table shows the list of menu items.

Main Menu	Sub Menu
System	Version
	Date & Time
	Maintenance
	Log & Report
	Language
Audio & Video	Camera
	Stream
	Audio
	PTZ protocol
	Preset

Main Menu	Sub Menu
Network	Basic
	RTP stream
	TCP/IP
	DDNS
	IP filtering
User	Basic
Schedule	Recording schedule
	Recording server
Event	Event schedule
	Event server
	Sensor & Relay

System settings

Version

Displays the current version of Firmware, Hardware, Software and Web Client.

Menu	Version
System	Version list
Version	Firmware version 09060901
Date & Time	Hardware version 4.1.0.99
Maintenance	Software version 4.1.0.090701
Log & Report	Web client version 4.1.0.185
Language	Copyright
Audio & Video	Copyright 2009 LG Electronics. All Rights Reserved.
Network	
User	
Schedule	
Event	

Date & Time

Menu	Date & Time
System	Time zone GMT
Version	
Date & Time	Time mode ☒ Synchronize with NTP server pool.ntp.org Time will be synchronized with NTP server every 1 hour Click button to test this server. [Test] ☐ Synchronize with personal computer 2009-07-21 14:15:28 ☐ Synchronize manually Date: 2009-07-21 [Calendar] Time: 14:14:15 Server time Server time 2009-07-21 05:15:28 [Save]
Audio & Video	
Network	
User	
Schedule	
Event	

Time zone

Set the time difference from GMT in the area where the IP device is installed.

Select the time zone in the area where the IP device is installed from the drop down list.

Time mode

- > Synchronize with NTP Server: Select if you want to synchronize the IP device's date and time with those of the time server called NTP (Network Time Protocol) Specify the NTP server's name. Click the [Test] button for connection test to the server.
- > Synchronize with personal computer: Select if you want to synchronize the IP device's date and time with that of your computer.
- > Synchronize manually: Select if you want to set the IP device's date and time manually. Select the year, month and date by clicking the calendar button. Set hour, minutes and seconds in the edit boxes.

Server time

- > Server time: Displays the current date and time of the IP device.
- Save: Click this button to confirm the settings.

Maintenance

Menu	Maintenance
System	System reboot
> Version	Click button to reboot this system. Reboot
> Date & Time	
> Maintenance	Restore and backup
> Log & Report	Click button to restore this configuration. Restore
> Language	Browse... Upload [ex. c:\backup.config]
Audio & Video	* Configuration file must be uploaded before restoring.
> Network	Click button to backup this configuration. Backup
> User	
> Schedule	Firmware
> Event	Click button to upgrade firmware. Upgrade
	Browse... Upload [ex. c:\firmware.dat]
	*Firmware file must be uploaded before upgrading.
	Click button to initialize the system. Initialize

System reboot

Click the [Reboot] button to restart the IP device. It takes some minutes for the IP device to start again.

Restore and backup

- > Backup: To take a backup of all of the settings. If necessary, it make possible to return to a backedup configuration. Click this button and follow the instructions on the browser to specify the folder and save the setting data of the IP device. This configuration backup can be restored when ever needed.

- > Restore: Click the [Browse] button and select the file in which the configuration setting data is stored and click the [Upload] button. Click the [Restore] button after successfully uploading the backup configuration. The System settings will be restored to the uploaded configuration and reboot the system.


Notes:

- Backup and Restore can happen on IP device having the same version of firmware. This feature is not intended for multi-configurations or for firmware upgrades.
- [Backup] function is allowed in HTTP protocol but not in HTTPS protocol.

Firmware

- > Upgrade
 1. Click the [Browse] button
 2. Find and open the firmware file.
 3. Click the [Upload] button.
 4. Click the [Upgrade] button to update the firmware.
- > Initialize: The [Initialize] button should be used with caution. Clicking it will return all of the IP device's settings to the factory default values. (Except for the Network settings, PTZ Protocol and Preset settings.)

Log & Report




Log & Report status

The System log provides a summary of the status of the IP device. The unit records the data of the software activity in a file.

- > View Log: Click this button to display the system log information.
- > View report: Click this button to display the report window of the system.

Language




Language list

Select a language for the LG Smart Web Viewer configuration menu and information display.

- Save: Click this button to confirm the settings.

Audio & Video settings

Camera



Preview

You can preview the camera image on the preview window.

General

- > Contrast: Edit the contrast value in steps of 1, from 0 to 100. Selecting 100 provides the image with the highest contrast.
- > Brightness: Edit to fine adjust the brightness of the camera. It is brighter when a large value is selected and it is darker when a small value is selected.
- > Standard: Displays the video standard of the camera.
- > Hue: Edit the video Hue of the camera from 0 to 100.
- Save: Click this button to confirm the settings.

- Default: Click this button to restore the IP device back to original factory settings.

Stream

Menu	Stream
System	Master
Audio & Video	Enable ☒ Deinterlacing ☒ Video codec: H264 Resolution: D1 Maximum frame rate: 30 [1~30 fps] GOP size: 30 [1~30] Quality: VBR Stream quality: MEDIUM
Camera	
Stream	
Audio	
PTZ protocol	
Preset	
Network	Slave
User	Enable ☒ Deinterlacing ☒ Video codec: H264 Resolution: D1 Maximum frame rate: 30 [1~30 fps] GOP size: 30 [1~30] Quality: VBR Stream quality: MEDIUM
Schedule	
Event	

Master/Slave

- > Enable: Click to activate the stream function.
- > Deinterlacing: Click to enable the use of deinterlacing function.
- > Video codec: Select the video mode (Codec) from the drop-down list. The viewer can choose between MJPEG and H.264.
- > Resolution: Select the image size to be sent from the camera.

NTSC:	D1 (704 x 480), HALF D1 (704 x 240), CIF (352 x 240) and QCIF (176 x 112)
PAL:	D1 (704 x 576), HALF D1 (704 x 288), CIF (352 x 288) and QCIF (176 x 144)

- > Maximum frame rate: Set the frame rate of the image. Selectable values of the frame rates are as follows.

NTSC:	1 to 30 (fps)
PAL:	1 to 25 (fps)

- > GOP size: It means "Group of Pictures". The higher the GOP, the better is the video quality of the camera. Edit the value of GOP from 1 to 30. This setting is valid for H.264 video format only.
- > Quality: Select the Quality.
 - VBR: The bit rate may vary depending on the complexity of the video to meet the selected quality.
 - CBR: The video quality may vary in order to preserve a constant bit rate.
- > Stream quality: If the [Quality] option set to VBR, this option is displayed. Select the stream quality from the drop down box, the camera supports five types (Highest, High, Medium, Low and Lowest)
- > Bit rate: If the [Quality] option set to CBR, this option is displayed. Edit the bit rate value from 64 kbps to 10 240 kbps.
- Save: Click this button to confirm the settings.

Audio

Menu

- System
- Audio & Video
 - Camera
 - Stream
 - Audio
 - PTZ protocol
 - Preset

Audio

Audio in

Enable ☐ Audio type G711 PCMA

Audio out

Enable ☐

Save

Audio In

- > Enable: Enables the check box when you are going to send the audio from the microphone input connector.

Note:

The Clients connected to the IP device remains unaffected with additional changes made in the setting.

- > Audio type: Select the codec when you send the audio from the microphone input connector.

Audio Out

- > Enable: Enables the check box to output the audio from the speaker.
- Save: Click this button to confirm the settings.

PTZ protocol

Allows the user to configure to different PTZ controls by using different PTZ protocols.

Menu

- System
- Audio & Video
 - Camera
 - Stream
 - Audio
 - PTZ protocol
 - Preset
- Network
- User
- Schedule
- Event

PTZ protocol

PTZ protocol list

PTZ protocol JIS MULTIX Edit

Upload PTZ protocol

Click button to upload PTZ driver.

Browse... Upload (ex. c:\protocol.ptz) Add PTZ protocol

*Protocol file must be uploaded before upgrading.

PTZ configuration

Enable ☒

Camera ID 0 [0~255]

Pan speed 100 [0~127]

Tilt speed 60 [0~127]

Zoom speed 3 [0~3]

Focus speed 3 [1~3]

Preset tour park time 1 [1~100]

Port

Baud rate 9600 Data bit 8

Parity NONE Stop bit 1

Save

PTZ protocol list

- > PTZ protocol: Displays the selected PTZ protocol.
- > Edit: Click to display the PTZ protocol window. Select the PTZ protocol and then click the [Save] button. If you want to delete the protocol, click the [Remove] button.

Upload PTZ protocol

Follow the instructions below to upload PTZ protocol.

1. Click the [Browse] button, find and open the file and then click [Upload] button.
2. Click the [Add PTZ protocol] button and then the PTZ protocol will be added.

PTZ configuration

- > Enable: Click to use the PTZ protocol.

- > Camera ID: Enter the PTZ device ID. Make the same ID as the PTZ Device.
- > Pan speed: Enter the panning speed of the PTZ device in the edit box. Default value for the LG Multix Protocol is 60 and ranges from 0 to 127.
- > Tilt speed: Enter the tilting speed of the PTZ device in the edit box. Default value for the LG Multix Protocol is 60 and ranges from 0 to 127.
- > Zoom speed: Enter the zoom speed of the PTZ device to view the object close or at a distance. Default value for the LG Multix protocol is 1 and ranges from 0 to 3.
- > Focus speed: Enter the focus speed of the PTZ device to focus an object clearly near or far. Default value for the LG Multix protocol is 1 and ranges from 1 to 3.
- > Preset tour park time: Enter the parking time.


Port

- > Baud rate: Select the desired speed of communication between the IP device and the PTZ Device. Confirm selected parameter to the baud rate of the IP device.
- > Data bit: Set the number of the data bits for RS-422/RS-485 communication.
- > Parity: Select the desired parameter. The parity bit, added to the data, to perform parity check.
- > Stop bit: Enter the desired parameter. The stop bit, added to the last of data, in asynchronous communication.
- Save: Click this button to confirm the settings.

Presets

Preview


You can see the settings screen from the preview window.



1. Move the camera to the point you want by using the arrow buttons.
2. Adjust the zoom, focus or iris options.
3. Set the Pan, Tilt, Zoom or Focus speed options.
4. Click the [Save] button to confirm the settings.

Pattern

You can activate the camera in a repeating pattern. The pattern is programmed by recording your manual pan, tilt, and zoom operations. The camera stores the movements you performed in memory.



> *To record the pattern*

1. Click the [Start recording] button to start the pattern recording.
2. Move the camera through the desired movement.
3. Click the [Stop recording] button to stop the pattern recording.

Note:

The available total time of pattern differs depending on connected PTZ device and operation.

> *To play the pattern*

1. Click the [Play] button to play the programmed pattern.
2. Click the [Stop] button to stop playing.

Preset list

Displays the registered preset position.



- Add: Click to add the preset position.
 1. Click the [Add] button.
 2. Select the preset index number.
 3. Enter the preset alias.
 4. Click the [Save] button.
 5. Repeat the steps 1 to 4 to add other positions.

Note:

If you set the HOME position, check the [Set home position] option.

- Remove: Click to delete the preset position.
 1. Select the preset from the list.
 2. Click the [Remove] button. The preset will be deleted.
- Go to preset: Move to the preset position.
 1. Select the preset from the list.
 2. Click the [Go to preset]. The camera will be moved to the selected preset.

Preset tour list

A preset tour is composed of a group of preset positions that the operator can link together in a sequence.



> *To tour the preset positions*

1. Choose the preset in the [Preset list].
2. Click the [Add] button in the [Preset tour list].
3. Repeat the steps 1 to 2 to add another preset.
4. Click the [Save] button to confirm the preset tour list.
5. Click the [Play] button to start the preset tour.
6. Click the [Stop] button to stop the preset tour.

Note:

If you control the PTZ or OSD, the preset tour will be stopped.

- Remove: Click this button to delete the selected preset in the [Preset tour list].

Network settings

Basic

Menu	Basic
System	General
Audio & Video	MAC address: 00:e0:91:85:64:08
Network	Port & Encryption
Basic	Web port: 80 [80,1025-65535]
RTP stream	RTSP port: 554 [554,1025-65535]
TCP/IP	Network encryption: HTTP
DDNS	TTL
IP filtering	TTL: 7 [1-255]
User	ARP Ping
Schedule	Enable ARP Ping to configure IP address: ☒
Event	Save

General

- MAC address: Displays the MAC address.

Port & Encryption

- Web port: The default HTTP port number (80) can be changed to any port within the range 1 025 to 65 535.
- RTSP port: Check RTSP port and the default port is 554. Other ports can be selected from the range 1 025 to 65 535.
- Network encryption: Select the HTTP or HTTPS option for security.

Note:

The RTSP port number should not be same with the web port number.

TTL

- TTL: This option indicates the Time-To-Live of multi-cast packets. The default setting is 7, and the allowed TTL range is from 1 to 255.

ARP Ping

- Enable ARP Ping to configure IP address: Check to enable ARP ping.
- Save: Click this button to confirm the settings.

RTP stream

RTP (Real-time Transport Protocol) is an internet protocol that allows programs to manage the real-time transmission of multi-media data, via unicast or multicast.

Menu	RTP stream
System	Master
Audio & Video	☒ RTP unicast
Network	☐ RTP multicast
Basic	Video RTP port: 8080 [1025-65534]
RTP stream	Audio RTP port: 7777 [1025-65534]
TCP/IP	Data RTP port: 8686 [1025-65534]
DDNS	IP address: 239.255.214.42
IP filtering	Slave
User	☒ RTP unicast
Schedule	☐ RTP multicast
Event	Video RTP port: 8080 [1025-65534]
	Audio RTP port: 7777 [1025-65534]
	Data RTP port: 8686 [1025-65534]
	IP address: 239.255.214.43
	Save

Master / Slave

- > RTP unicast: When enabled the transmission of the data to the specified equipment happens on a network specifying a single address.
- > RTP multicast: When enabled it reduces the transmission load on the camera by making the computer of the same segment network receive the same transmission data. When multicast option is checked then select Video Port number, Audio Port number and Data port number.

- Video RTP port: Specify the video transmission port number used for the multicast streaming. It is initially set to 8888 and you can edit this between 1 025 and 65 534.
- Audio RTP port: Specify the audio port number used for the multicast streaming. It is initially set to 7 777 and you can edit this between 1 025 and 65 534.
- Data RTP port: Specify the VA data port number used for the multicast streaming. It is initially set to 6666 and you can edit this between 1 025 and 65 534.
- IP address: Set the IP address for RTP multicast.

Note:

Each stream using multicast needs its own a pair of multicast IP address and port numbers to avoid address conflict.

- Save: Click this button to confirm the settings.

TCP/IP

Menu		TCP/IP	
System		IP address status	
Audio & Video		☐ Automatically set with DHCP	
Network		Notify to SMTP server, if IP address is changed. Nothing	
Basic		☒ Statically set	
RTP stream		IP address 10.164.64.32	
TCP/IP		Subnet mask 255.255.255.0	
DDNS		Gateway 10.164.64.1	
IP filtering		DNS server status	
User		DNS server 156.147.151.32	
Schedule		Secondary DNS server 165.244.106.110	
Event		Save	

IP address status


- > Automatically set with DHCP: Select this option when a DHCP server is installed on the network to allow IP address assignment. With this setting, the IP address is assigned automatically.
 - Notify to SMTP server, if IP address is changed: If you select this option, the user get a notification mail telling him that the IP of the IP device has changed.
Note:
You should register the SMTP server on the Event server setting to set this function.
- > Statically set: Select this option when you set a fixed IP address, with this setting, specify the IP address, Subnet mask and default gateway manually.
 - IP address: Enter an IP address.
 - Subnet mask: Enter a subnet mask address.
 - Gateway: Enter the gateway address.

DNS server status

- > DNS server: Enter the Primary domain name server that translates the hostnames into IP address.
- > Secondary DNS server: Enter the Secondary DNS server address that backups the Primary DNS.
- Save: Click this button to confirm the settings.

DDNS

This free service is very useful when combined with the LG DDNS Server. It allows the user to connect the IP device using the URL, rather than an IP Address. This also solves the problem of having a dynamic IP address.




DDNS status

- > Don't use DDNS server: Disable the DDNS function.
- > Use DDNS server: Enable the DDNS function.
 - Provider: Displays the DDNS provider.
 - Hostname: Enter the hostname you want to use.
- Save: Click this button to confirm the settings.

IP filtering

The access of the IP addresses in the list are allowed or denied according to the choice made in the drop-down list of the Basic policy option. The administrator can add up to 10 IP address entries to the list (a single entry can contain multiple IP addresses). The users from these IP addresses need to be specified in the user list with the appropriate access rights. The IP list is to control the access permission of clients by checking the client IP address.



IP list

- > Basic policy: Select the basic policy type.
 - Allow all: Allow all the IP address basically, but the IP addresses in the list are denied.
 - Deny all: Deny all the IP address basically, but the IP addresses in the list are allowed. It needs at least one IP address to activate this function.
- Save: Click this button to confirm the settings.
- Add: Click this button to add the IP address.
 1. Click the [Add] button.

2. Set the IP options.
 - Alias: Enter the alias.
 - From: Enter the start IP address for the IP filtering.
 - To: Enter the end IP address for the IP filtering.

Note:

If you want to deny or to allow a range of IP addresses, enter the start IP address to “From” and the end IP address to “To”. You can also add an IP address by entering the IP address to “From” and “To”.

3. Click the [Save] button.
 4. Repeat the steps 1 to 3 to add additional IP address.
- Remove: Click this button to delete the IP address.
 1. Select the alias from the list.
 2. Click the [Remove] button. The IP address will be deleted.

User settings

Basic

The IP device is shipped with the login rights of administrator only. If others need to access the IP device excluding the configuration a login with viewer rights need to be created. A maximum of 50 users can be created.

User list

> Add the User

You can register a new user with various access rights.

1. Click the [Add] button. User setting dialog is displayed.
2. Enter the new User ID and Password. (Should have a minimum of 4 characters and preferably a combination of alphanumeric).
3. To confirm the password, retype the password that you typed in the Password box.
4. Select the authority drop down list to provide the access rights to each user and then click the [Save] to confirm your selection.
 - Administrator: Allows you to operate setup menus and to view live images.

- Power user: Use of the limited functions of the system (The Configuration menu is not allowed. A power user can use the Live View, PTZ control, OSD control and audio functions.
- Normal user: Provides the lowest level of access. Allows to view live images only.
- Custom user: The user can login and view the live stream image only when the “Enable anonymous login” option is checked to enable it.

Note:

Remember the password.

> *Edit the registered user*

You can change the password or authority.

1. Choose the user ID and then click the [Edit] button.
2. Change the Password or Authority, then click the [Save] button to confirm your selection.

> *Delete the registered user*

1. Choose the user ID you want to delete.
2. Click the [Remove] button.

Note:

The default administrator user ID ‘admin’ is permanent and cannot be deleted.

Anonymous

> *Enable anonymous login*

Check the box to enable anonymous user login
- allows the user access for only viewing the live stream image.

Maximum RTP stream connection

- > Maximum number of simultaneous stream connection.

Set this number to limit the number of simultaneous stream connections.

Note:

Preview window of the IP device setting and preset setting are affected by this setting.

- Save: Click this button to confirm the settings.

Schedule settings

Recording schedule

This IP device provides video monitoring, recording and event management functions. Users can record video continuously, on schedule, on alarm and/or on Video Contents Analysis (Optional).

To set the Recording Schedule

1. Click the [Add] button. Recording schedule setting window is displayed.
2. Set the [Pre alarm] and/or [Post alarm] option.
 - Pre alarm: Specifies the maximum recording capacity of the image before the event detection.
 - Post alarm: Specifies the maximum recording capacity of the image after the event detection.
3. Select the Repeat type. It can be configured in 5 different ways, Repeat None, Daily, Weekly, Monthly and Yearly.
4. Set the [Custom day] option. This option is available if the repeat option is None. Here a calendar is provided to mark the event detection activity.
5. Set the Activation Time parameters (24h clock) for the event.
 - NONE: No scheduled recording
 - CONTINUITY: Recording starts automatically from the preset time.
 - VA: Recording starts automatically when the object or event is detected within a designated time.
 - SENSOR: Recording starts automatically when the sensor input of the IP device is activated within a designated time.
 - DUPLICATED (C,V): Recording starts automatically from the preset time. When the object or event has been detected within a designated time, change the continuous recording mode to VA event recording mode and recording starts

automatically.

- DUPLICATED (C,S): Recording starts automatically from the preset time. When the sensor input is activated within a designated time, change the continuous recording mode to the sensor event recording mode and recording starts automatically.
 - DUPLICATED (V,S): Recording starts automatically when the object or event is detected or the sensor input is activated within a designated time.
 - DUPLICATED (C,V,S): Recording starts automatically from the preset time. When VA or SENSOR event is detected, change the continuous recording mode to the VA event recording mode or the sensor event recording mode.
6. Click the [Save] button to confirm the settings.

To edit the Recording Schedule

1. Choose the particular schedule in the Total schedule list that needs to be edited.
2. Click the [Edit] button.
You can check or edit the the recording schedule options .

To activate the Recording Schedule

1. Set the [Stream] option. This would give an option to set either the Master stream or the Slave stream for recording
2. To allocate a recording schedule choose the particular one and click the [Allocate] button.

To deactivate the Recording Schedule

1. Choose the schedule in the Schedule list.
2. Click the [DeAllocate] button.

To delete the Recording Schedule

1. Choose the particular schedule from the Total Schedule list.
2. Click the [Remove] button.

Recording server

Recording server is used to save the recorded data files.

The screenshot shows the 'Recording server' configuration window. On the left is a 'Menu' sidebar with icons and labels: System, Audio & Video, Network, User, Schedule, Recording schedule, and Event. The main area is titled 'Recording server' and contains the following settings:

- ☐ Enable
- Address: [text box]
- User ID: [text box] Password: [text box]
- Folder: [text box] Type: [CIFS dropdown]
- Capacity: [0] (GB) Overwrite: ☒
- Disk full notification of recording server.**
- ☐ Control relay: [Relay-0 dropdown] ☐ SMTP server: [text box]
- [Save button]

Recording server

These options can be set by using the LG Smart Station program. (Display only in this LG Smart Web Viewer program.)

Disk full notification of recording server.

- > Control relay: Marks up to activate the alarm. Alarm is activated when the Recording Server is full and has no place to record.
- > SMTP server: Select the SMTP server address. Sends an e-mail when the Recording Server has no further place to record.

Note:

You should register the SMTP server on the Event server setting to set this function.

- Save: Click this button to confirm the settings.

Event settings

Event schedule

When an event (VA/Sensor Event) occurs, this unit records the live images and routes as configured.

Menu	Event schedule						
System	Event schedule list						
Audio & Video	Trigger	Relay	FTP server	SMTP server	Preset	Pre alarm	Post alarm
Network	Sensor-0	Relay-0				5	5
User	VA_Intrusion-0					5	5
Schedule	VA_Tripwire-0					5	5
Event	VA_ObjectCounting-0					5	5
Event schedule	VA_ObjectRemoval-0					5	5
Event server	VA_Tampering-0					5	5
Sensor & Relay							

Event schedule list

> To edit the Event Schedule

1. Click the Trigger event in the event schedule list. Event schedule window is displayed.
2. Set the options.
 - Trigger: Displays the selected trigger event.
 - Time: Sets the weekday, Start, Finish, Pre alarm, Post alarm and Ignore interval time options.
 - Action: Selects the options. This occurs when the event runs.
 - FTP server/SMTP server: Uploading of images to an FTP server, or e-mail notification.
 - Move camera to: Moves the camera to preset position.

- Control relay: The relay is activated or deactivated.
- Stream: Selects the stream of the connected camera.
 - Default: Sets to default setting value.
3. Click the [Save] button to confirm the settings.

Note:

You should register the SMTP and FTP server on the Event server setting to set this function.

Event Server

Event Servers are used to receive the recorded video clip and/or notification messages.

Menu	Event server
System	FTP server list
Audio & Video	Address Alias
Network	
User	
Schedule	
Event	Add Edit Remove
Event schedule	SMTP server list
Event server	Address Alias
Sensor & Relay	
	Add Edit Remove

FTP server list

Image files can be transferred to the FTP server within the scheduled time. Image file that has been recorded linked to an external event is sent to the FTP server periodically.

> *To add the FTP server*

1. Click the [Add] button. FTP server setting window is displayed.
2. Set the FTP server options.
 - Alias: Type the FTP Server name to upload the image files.
 - Address: Enter the FTP server's IP address.
 - Port: Enter the port number. The default FTP port is 21.
 - User ID: Type the user name for the Folder shared in the FTP server.
 - Password: Type the password for the folder shared in the FTP Server.
 - Folder: Type the path with the folder that is shared in the FTP server.
3. Click the [Save] button to confirm the settings.

> *To edit the FTP server*

1. Choose the FTP server in the FTP server list.
2. Click the [Edit] button.
You can check or edit the FTP server options.

> *To delete the FTP server*

1. Choose the FTP server in the FTP server list.
2. Click the [Remove] button. This would remove the FTP server from the list.

SMTP server list

By selecting the e-mail option, a still image of the event is captured and an e-mail with the image file attached is sent to the specified mail address.

> *To add the SMTP server*

1. Click the [Add] button. SMTP server setting window is displayed.
2. Set the SMTP server options.
 - Alias: Enter the SMTP server name.
 - User ID: Enter the user ID of the SMTP server. This would be the one who owns the mail account.
 - Password: Enter the password. This password of the same account.
 - Address: Enter the SMTP server address.
 - Port: Enter the port number. The default port is 25.
 - Enable SSL: Check when use the SSL (Secure Socket Layer) protocol. SSL protocol is cryptographic protocols that provide secure communication on a network.
 - Receiving address: Type the recipients e-mail address. You can specify only one recipient e-mail address.
 - Administrator address: Type the e-mail address of the administrator.
 - Subject: Enter the subject/title of the e-mail.
 - Message: This message can describe the information of the acquired IP address, etc.
3. Click the [Save] button to confirm the settings.

- > *To edit the SMTP server*
 1. Choose the SMTP server in the SMTP server list.
 2. Click the [Edit] button.
You can check or edit the SMTP server options.
- > *To delete the SMTP server*
 1. Choose the SMTP server in the SMTP server list.
 2. Click the [Remove] button.

Sensor & Relay

Menu	Sensor & Relay		
System	Sensor		
Audio & Video	Enable	Alias	Type
Network	☒	Sensor-0	Normal open
User	Relay		
Schedule	Control duration [1-86400(24hour), second]	Alias	Control relay
Event	5	Relay-0	Run Stop
	Save		

Sensor

- > Enable: Marks up when you want to activate the sensor.
- > Alias: Displays the sensor name.
- > Type: Select the sensor type.

Relay

- > Control duration: Enter the relay time.
- > Alias: Displays the relay name.
- > Control relay
 - Run: Click to activate the relay.
 - Stop: Click to stop the relay.
- Save: Click this button to confirm the settings.

Reference

Troubleshooting

This section provides useful information to help you to resolve any difficulty you might have with your LG IP device. Fault symptoms, possible causes and remedial actions are provided here.

IP Setting problems

- ARP/Ping: Disconnect and reconnect the power to the network camera. The device should get the ip within 2 minutes.
- Ping your camera: Open the command prompt on your computer, type ping with the IP address of the network device. The reply obtained by this command provides explanation for the cause of the problem.
 1. bytes = 32 time = 2 ms indicates that the IP address is already used and cannot reuse the same. A new IP address needs to be obtained.
 2. Destination host unreachable: indicates that the network device and your computer do not fall in the same subnet hence needs to get a new IP address. Contact the system administrator for the required help.
 3. Request timed out: Indicates that the IP is free as it is not used by anyone and the network device can obtain this.
- IP Conflicts: If the LG network device is set with a static IP address and if the DHCP option is set then there may be ip's same as the network device and other network partner. Hence set the static IP address to 0.0.0.0 to resolve this conflict.

Cannot access the camera from browser:

- Reconnect the network camera with power and check the ping operation to know if the IP is used by others.
- Disable the proxy setting in the Browser if you are using a proxy server.
- Check for proper cabling and network connections, try to ping after verifying the connectivity.
- Sometimes when HTTPS is enabled, we would be checking the URL with http, in this case manually change the URL to the http/https accordingly.
- Verify the DNS and Gateway settings if the IP address is assigned statically to the network device.

Accessing camera external to the local network

- Firewall Protection: Check for the internet firewall with the system administrator, either he has to do port forwarding or modify the DMZ function on the router.
- Default router needed: Check if you need configure the router settings.

Sporadic network performance

- Network Switches or hubs used may be of the lower configuration and the load on this may not meet the required conditions of our network camera.
- Check for the RJ-45 cables that are used for the network connectivity.
- If POE is used check if the power is got by the network camera when connected to it.

Login Password lost

- Reset the camera by pressing the Reset button for more than 3 seconds to restore default settings.
- After the factory settings login using the default user name and password.

Video Streaming problems

- If the video streaming does not start on the Web client as per the indication install the latest version of JRE (Java Run Time) on your computer.
- When Windows IE browsers are used always take care to allow pop ups, check this option before we run the web client.
- Check the quality of image by referring the video settings as described in the manual.
- Sometimes there would be intermittent or very slow video streaming, this may be because of the higher resolution and frame rate that are set for the video.
- The video streaming may appear poor at times, this may be because of the network traffic ,too many devices connected to the switch or hub, enabling motion detection to each of the video streams and because of other programs running on your computer.
- If the images appear to be blurred adjust the focus of the network camera to get a clear image.
- Video images if appear white and black adjust the settings in the OSD to get back the colorful image.
- Select the Night mode if the network camera is connected at a place where surrounding light is less or dark.

- If we obtain lower frame rate than set we need to check from the system administrator for sufficient bandwidth available or reduce the number of applications running on the client computer.
- If the client PC's are unable to access the multicast stream, check with the system administrator for the use of a valid multicast address or check if the router is supporting multicasting.
- If the images appear to have white or gray stripes on it, upgrade the Video graphics driver on the client PC to the latest version.
- Video images may be noisy if you are using the camera in a very low light environment or the bit rate/quality is set to very low values. Provide higher values for quality and support the surrounding environment with enough light.

Audio condition

The client computer that is interacting with the camera needs to have a sound card that is functional to support speaker and microphone.

The sound card needs to be checked for its support for full duplex communication.

Ensure that the mute button of the client computer is not set and all the audio settings are correct.

Speaker button on the web viewer should be enabled to listen the audio from the network camera.

Ensure that the bidirectional audio button is enabled on the Web viewer and the microphone is set.

Change the input and the output gain for microphone and the speaker respectively to set correct audio level.

For all further support please contact the supplier or forums or websites.

Open source software notice

The following GPL executables and LGPL libraries used in this product are subject to the GPL2.0/LGPL2.1 License Agreements:

GPL EXECUTABLES:

Linux kernel 2.6, bash, busybox, gdbm, libreadline, module-init-tools, mount, mtd-utils, net-tools, quftp, tar, util-linux

LGPL LIBRARIES:

Glibc, libelf, libesmtp, live.media

LG Electronics offers to provide source code to you on CD-ROM for a charge covering the cost of performing such distribution, such as the cost of media, shipping and handling upon e-mail request to LG Electronics at:

opensource@lge.com

This offer is valid for a period of three (3) years from the date of the distribution of this product by LG Electronics.

You can obtain a copy of the GPL, LGPL licenses from <http://www.gnu.org/licenses/old-licenses/gpl-2.0.html> and <http://www.gnu.org/licenses/old-licenses/lgpl-2.1.html> .

This product includes mDNSResponder component which is licensed under the terms of the Apache License, Version 2.0.

You can obtain a copy of the Apache license from <http://www.apache.org/licenses/LICENSE-2.0.html>.

This product includes

- dhcp client :
 - Copyright © 2004-2008 by Internet Systems Consortium, Inc. ("ISC")
 - Copyright © 1995-2003 by Internet Software Consortium
- expat library : Copyright © 2006 expat maintainers.
- libcap
- libjpeg : Independent JPEG Group Copyright © 1991 - 1998, Thomas G. Lane.
- libmd5 : Copyright © 2002 Aladdin Enterprises.
- libncurses : Copyright © 1998,2002 Free Software Foundation, Inc.
- libpcre : Copyright © 1997-2009 University of Cambridge
- UPnP SDK : Copyright © 2000-2003 Intel Corporation
- libxml2 : Copyright © 1998-2003 Daniel Veillard.
- lighttpd : Copyright © 2004, Jan Kneschke, incremental
- ntpdate : Copyright © David L. Mills 1992-2006
- OpenSSL :
 - > cryptographic software written by Eric Young (eay@cryptsoft.com).
 - > software written by Tim Hudson (tjh@cryptsoft.com).
 - > software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org>)
- PHP software, freely available from <http://www.php.net/software/> : Copyright © 1999 - 2009 The PHP Group.
- Speex :
 - > Copyright 2002-2008 Xiph.org Foundation
 - > Copyright 2002-2008 Jean-Marc Valin
 - > Copyright 2005-2007 Analog Devices Inc.
 - > Copyright 2005-2008 Commonwealth Scientific and Industrial Research Organisation (CSIRO)
 - > Copyright 1993, 2002, 2006 David Rowe
 - > Copyright 2003 EpicGames

- > Copyright 1992-1994 Jutta Degener, Carsten Bormann
- Zlib : Copyright © 1995-2002 Jean-loup Gailly and Mark Adler.

All rights reserved.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Specifications

Item	LVS301	LVS311
Resolution (Max)	704 x 480 (NTSC), 704 x 576 (PAL)	
Output	RJ-45 (Network), CVBS (Monitor)	
Frame Rate(Max)	30 fps/25 fps (NTSC/PAL)	
Compression	H.264 (Basic Profile) / MJPEG Dual Stream	
Audio	Full Duplex(Line level input/output) - Audio Input 1Ch, Audio Output 1Ch	
Audio Compression	G.726, G.711 (A-law, u-law)	
Sensor/Relay	1 digital input, 1 relay output	
VCA (Video Contents Analysis)	Intruder detection(Optional)	
	Tripwire(Optional)	
	Object Removal(Optional)	
	Object Counting(Optional)	
	Tampering(Optional)	
Event Detection	Sensor In	Sensor In, VCA
Event Notification	Relay, SMTP, FTP	
ID/Password	Multi level user ID/password (Admin, Power, Normal, Customer)	
Encryption	HTTPS(SSL,TLS)	

Item	LVS301	LVS311
Physical Layer	10/100 base TX Ethernet	
Protocol	TCP/IP(IPv4), HTTP, HTTPS, RTP, RTSP, UDP, DHCP, FTP, SMTP, NTP, ARP, ICMP, DDNS(LG)	
IP support	Dynamic, Static, Private IP	
Users	Unicast 10 Streams / 50 user registration	
Operation Temp. / Humidity	-10 °C to 50 °C / 0 %RH to 80 %RH	
Power Source	PoE, AC 24 V (±20 %) (1 A or above), DC 12 V (±10 %) (2 A or above)	
Power Consumption	About 7 W	
Dimension (W x H x D)	170.4 mm x 56.2 mm x130.2 mm	
Weight	0.73 kg	
Other	RS-485 / RS-422 Support	

