

FeeMaster Lite Attendant's Console

PRODUCT DESCRIPTION



The FeeMaster Lite is part of the FeeMaster product family, a time-based parking management system that provides a simple and cost-effective way of managing car parking access and controlling access validity periods without the need for expensive cabling between components.

The FeeMaster Lite console provides an extremely simple and cost-effective means of issuing exit tokens to authorised car park users. Designed to provide a means of protecting free parking spaces, it's an ideal solution for hospitals, schools, colleges and hotels. It can also be used for the management of fixed-fee parking.

Tickets issued at the entry station show the time of arrival. Car park users simply take their tickets to an attendant, who then issues them with a ticket that will allow them to exit.

FEATURES

- Simple to install and operate
- Standalone operation
- Single button press to issue a ticket
- Prints a barcode exit ticket via an attached POS printer
- Data includes station number, unique ticket number and grace period (up to 255 minutes)
- Configurable message on exit ticket (up to 6 lines)
- All settings configurable from a PC (temporary connection to PC)
- Connection to PC USB port via USB/RS485 converter
- Event logging and reporting (temporary connection to PC)
- Coming soon: personalized logo on tickets

Tickets are issued by a simple button press and all transactions are automatically logged to enable auditing. This deters unauthorised parking and facilitates fixed fee charging, where required.

Attendants' stations may be set up anywhere that has a mains supply available and multiple attendants' stations are supported. FeeMaster Lite offers one of the most reliable and cost-effective ways of managing car parks.

SPECIFICATIONS

Electrical

Supply Voltage: 24V DC (in-line mains adaptor is included)

Physical

Controls: Single push-button

Dimensions (mm): 135 x 145 x 260 (H x W x D)

Outputs

POS Printer: RS232 (9-pin D-type)

Data Communication

PC Interface: RS485 (9-pin D-type) to USB converter at PC.

Ordering Information

PRK102 (FM-BUTTON-ENC)

FeeMaster desktop push-button console. Links directly to BCP-FM to allow exit tokens to be printed. Requires FM-LITE software for configuration.


Included with PRK102: **BCP-FM**

Barcode token/customer receipt printer for use with the FeeMaster attendant's console. Includes in-line mains power adaptor.

PRK101 (FM-LITE)

PC software for configuration and data collection for use with FM-BUTTON-ENC. Includes a USB interface adaptor for connection between the PC and the console.

Connection Details



Receipt Printer

Attendant's Console

Management PC

*onder voorbehoud van wijziging - de hierboven vermelde gegevens zijn louter informatief en niet bindend
sous réserve de modifications - les données ci-dessus ne sont mentionnées qu'à titre informatif, sans engagement*

UW PARTNER IN AUTOMATISATIE – VOTRE PARTENAIRE EN AUTOMATISATION