


Internal expansions and interfaces

ESP4-20	    
	Mounting position A B C Expansion module with 4 inputs for connecting conventional, RDV® and Zone Bus detectors from Tecnoalarm - EN 50131-3 certification Item no. F127TP420ESP
ESP LAN	    
	Mounting position A B C Ethernet-Interface for the transmission of alarm notifications and the management of the telematic services TCS, DDNS Tecnoalarm, SNTP and Mail Server Tecnoalarm through the remote management software with TCP/IP - EN 50131-3 certification Item no. F127ESPLAN
ESP GSM 4G	   
	Mounting position A B C Interface for connecting the control panel to the mobile network - Transmission of alarm notifications and management of the telematic service TCS through the remote management software with TCP/IP - Compatible with all GSM formats from 2G GPRS to 4G LTE - Manages the VoLTE service - EN 50131-3 certification Item no. F127ESPGSM4G
ESP GSM LINK	
	Mounting position A B C Interface for connecting the TECNOCELL 4 communicator via RS422 serial bus - In this configuration, the TECNOCELL 4 communicator emulates the operation of the ESP GSM 4G interface Item no. F127ESPGSMLINK

SOFTWARE PLUG-INS

ADVANCED PROGRAMMING	 Advanced programming software plug-in N.B. Function subject to license. Indicate serial number of control panel in order. Item no. F127T42/AV
-----------------------------	--