




P/N	description
-----	-------------

T50 Actuator kit (master)

3C20001	T50 Rack actuator 230V stroke 32 cm (adjustable)
3C20002	T50 Rack actuator 230V stroke 50 cm (adjustable)
3C20013	T50 Rack actuator 230V stroke 75 cm (adjustable)
3C20003	T50 Rack actuator 24V stroke 32 cm (adjustable)
3C20004	T50 Rack actuator 24V stroke 50 cm (adjustable)
3C20014	T50 Rack actuator 24V stroke 75 cm (adjustable)

T50 Rack assembly kit (slave)

3C2100	T50 Rack assembly stroke 32 cm (connection and fitting accessories included)
3C2101	T50 Rack assembly stroke 50 cm (connection and fitting accessories included)
3C2104	T50 Rack assembly stroke 75 cm (connection and fitting accessories included)

T50 connection rod

1C2505	T50 connection rod - Length 150 cm (interaxis max. 140cm)
1C2509	T50 connection rod - Length 300 cm (interaxis max. 240cm)


Description of the standard pattern for 2 push points

3C20001	T50 Rack actuator 230V stroke 32 cm (adjustable)
3C2100	T50 Rack assembly stroke 32 cm
1C2505	T50 Connection rod - Length 150 cm

Description of the standard pattern for 3 push points

3C20001	T50 Rack actuator 230V stroke 32 cm (adjustable)
3C2100	T50 Rack assembly stroke 32 cm
3C2100	T50 Rack assembly stroke 32 cm
1C2509	T50 Connection rod - Length 300 cm

Accessories and spare parts



3C2010	Actuator support brackets
3C2001	Spare parts and sash bracket
1C2804	Junction ring between the connection rods for 3 push point
OA0483	Connection rod stop